

89A.14 Continuing duty of owner.

Every conveyance shall be maintained by the owner in a safe operating condition and in conformity with the rules adopted by the safety board.

[C75, 77, 79, 81, §104.14]

C87, §89A.14

[2004 Acts, ch 1107, §24, 30; 2007 Acts, ch 16, §13](#)