

**875—73.6 (89A) Machines.**

**73.6(1)** Friction gearing or clutch mechanisms shall not be used for connecting the drum or sheaves to the main driving mechanism.

**73.6(2)** Set screw fastenings shall not be used on power elevators in lieu of keys or pins on connections subject to torque or tension.

**73.6(3)** Portable power-chain or cable hoist machines shall not be used to raise or lower an elevator car.

**73.6(4)** No belt or chain driven power machine shall be used for any elevator unless the machine is provided with a broken belt or broken chain safety switch of the electrical nonautomatic reset type.  
EXCEPTION: Hydraulic machines.